

X10000 G3存储安装handy包提示错误:ERROR: Port 5432 is already in use, Please check which process is occupied and stop it

安装扩容 郭聪 2022-04-29 发表

组网及说明

X10000标准组网。

告警信息

集群已经成功部署,在另一个节点安装Handy包,准备部署Handy HA,在安装Handy时提示报错: ER ROR: Port 5432 is already in use, Please check which process is occupied and stop it. 报错截图如下:

问题描述

集群已经成功部署,在另一个节点安装Handy包,准备部署Handy HA,在安装Handy时提示报错: ER ROR: Port 5432 is already in use, Please check which process is occupied and stop it. 报错截图如下:

1、使用命令netsat-anp | grep 5432 查看5432端口占用进程:

```
SYN_SENT
SYN_SENT
SYN_SENT
SYN_SENT
SYN_SENT
SYN_SENT
SYN_SENT
tcp
tcp
tcp
                                                                                                                                                                                                                                                              617654/python
606089/python
616227/python
                                                                                                                                                                                                                                                              625292/python2.7
618076/python
609453/python
619141/python
tcp
tcp
tcp
                                                                                               94:60508
94:58624
                                                          root@X10
                                                                                                                                                                                                                      SYN_SENT
SYN_SENT
SYN_SENT
SYN_SENT
SYN_SENT
SYN_SENT
SYN_SENT
                                                                                                                                                                                                                                                            617654/python
606089/python
616227/python
625292/python2.7
618076/python
609453/python
619141/python
                                                                                                                                           27.0.0.1:5432
27.0.0.1:5432
27.0.0.1:5432
  cp
cp
tcp
tcp
tcp
tcp
                                                                                                                                           27.0.0.1:5432
27.0.0.1:5432
27.0.0.1:5432
27.0.0.1:5432
                                                                                                94:33582
                                                                                               94:60508
94:58624
94:60668
                                                            10.
10.
10. .
~]# netstat
                                                                                                -anp |grep 5432
94:60456 27.
  root@
                                                                                                                                                                                                                       SYN_SENT
SYN_SENT
SYN_SENT
SYN_SENT
SYN_SENT
SYN_SENT
SYN_SENT
                                                                                                                                                                                                                                                            617654/python
616227/python
625292/python2.7
630571/python
631416/python
618076/python
609453/python
tcp
tcp
                                                                                               94:60078
94:33582
94:34748
 tcp
tcp
tcp
                                                                                                94:34870
                                                                                                94:58624
                                                              ~]# [
```

- 2、发现这些进程在被27.0.0.1,同时使用ps -elf |grep pid (pid为进程id号,请根据实际情况修改),发现prometheus-node进程号一直在变化。
- 3、使用supervisorctl status命令观察prometheus-node进程在反复重启,(可观察如图进程运行时间)

```
~]# supervisorctl status
RUNNING
[root@X:
onestor-bm
                                                                    pid 454518, uptime 0:19:26
                                                                    pid 454515, uptime 0:19:26
pid 454512, uptime 0:19:26
pid 454519, uptime 0:19:26
                                                    RUNNING
RUNNING
onestor-csc
onestor-mr
 onestor-nm
                                                    RUNNING
                                                                   pid 454517, uptime 0:19:26
pid 454516, uptime 0:19:26
pid 454516, uptime 0:19:26
pid 454510, uptime 0:19:26
pid 454514, uptime 0:19:26
pid 680426, uptime 0:00:12
onestor-peon
onestor-sub
                                                    RUNNTNG
                                                    RUNNING
 onestor-tier
                                                    RUNNING
 onestor-worker
                                                    RUNNING
 rometheus-node
                                                    RUNNING
 rooτ@xi
root@X1
 root@X1
                               √]# supervisorctl status
                                                                    pid 454518, uptime 0:19:34
pid 454515, uptime 0:19:34
onestor-bm
                                                    RUNNING
 onestor-csc
                                                    RUNNING
                                                                    pid 454512, uptime 0:19:34
pid 454519, uptime 0:19:34
pid 454517, uptime 0:19:34
 onestor-mr
                                                    RUNNING
 onestor-nm
                                                    RUNNING
 onestor-peon
                                                    RUNNING
                                                                    pid 454516, uptime 0:19:34
pid 454510, uptime 0:19:34
pid 454514, uptime 0:19:34
onestor-sub
                                                    RUNNING
 onestor-tier
                                                    RUNNING
 onestor-worker
                                                    RUNNING
 orometheus-node
                                                    RUNNING
                                                                   pid 680426, uptime 0:00:20
                               ~]<mark># supervis</mark>o
                                                    cil statu
RUNNING
RUNNING
                                                                    pid 454518, uptime 0:24:07
onestor-bm
                                                                    pid 454515, uptime 0:24:07
pid 454515, uptime 0:24:07
pid 454512, uptime 0:24:07
onestor-csc
 onestor-mr
                                                    RUNNING
                                                                    pid 454519, uptime 0:24:07
pid 454517, uptime 0:24:07
                                                    RUNNING
onestor-nm
 onestor-peon
                                                    RUNNING
                                                                    pid 454516, uptime 0:24:07
pid 454510, uptime 0:24:07
pid 454514, uptime 0:24:07
onestor-sub
                                                    RUNNING
 onestor-tier
                                                    RUNNING
 onestor-worker
                                                    RUNNING
                                                    RUNNING
                                                                   pid 729786, uptime 0:00:53
 rometheus-node
 root@X
                               /]# supervisorctl status
                                                    RUNNING
RUNNING
                                                                    pid 454518, uptime 0:24:18
pid 454515, uptime 0:24:18
pid 454512, uptime 0:24:18
onestor-bm
onestor-csc
 onestor-mr
                                                    RUNNING
                                                                    pid 454519, uptime 0:24:18
pid 454517, uptime 0:24:18
onestor-nm
                                                    RUNNING
onestor-peon
                                                    RUNNING
 onestor-sub
                                                    RUNNING
                                                                    pid 454516, uptime 0:24:18
                                                                    pid 454510, uptime 0:24:18
pid 454510, uptime 0:24:18
pid 454514, uptime 0:24:18
onestor-tier
                                                    RUNNING
 onestor-worker
 rometheus-node
                                                    RUNNING pid 741730, uptime 0:00:04
                             ~]#
```

4、基本可以判定是由于prometheus-node进程在反查重启占用5432端口导致,结合第一步看到的ip地址27.0.0.1,想到回环地址127.0.0.1,且本节点进程应该是本节点自己占用,故排查etc/hosts文件中的回环地址是否正确。查看现场的etc/hosts回环地址,可以看到如图,其地址被篡改为27.0.0.1,故造成了上述问题。

解决方法

修改etc/hosts配置文件,修改其回环地址为正确的127.0.0.1,然后重启supervisorctl服务,重启命令为: supervisorctl restart all (该命令会中断handy界面正在下发的配置流程业务,不会影响已有的生产业务。)