Why can't I configure an auto AP?

Problem Description

Why can't I configure an auto AP?

Solution

An auto AP does not have an AP view and cannot be configured. To configure auto APs, you must convert auto APs to manual APs by executing the wlan auto-ap persistent all command.