

配置步骤

V7交换机Console密码忘记处理方法

目录

[V7交换机Console密码忘记处理方法](#)

[1 配置需求或说明](#)

[1.1 适用产品系列](#)

[1.2 配置需求及实现的效果](#)

[2 组网图](#)

[3 配置步骤](#)

[3.1 进入bootroom菜单清除Console密码](#)

[3.2 如果不需要之前的配置信息的话](#)

[3.3 如果需要之前的配置信息的话](#)

1 配置需求或说明

1.1 适用产品系列

本案例适用于如 本案例适用于如S5500V2-34S-EI、S5500V2-28F-SI、S5530F-EI-D、S5560-54C-EI、S5560X-54C-PWR-EI、S5820V2-52Q、S5820V2-52QF-H3等S5500V2、S55X0、S58X0V2系列的**交换机** 等的V7交换机，V5、V7交换机具体分类及型号可以参考“1.1 Comware V5、V7平台交换机分类说明”。

1.2 配置需求及实现的效果

清除Console密码，恢复出厂

2 组网图

无

3 配置步骤

3.1 进入bootroom菜单清除Console密码

通过console线和port软件连接并登陆设备，然后把设备断电重启。控制台上会打印如下信息，当出现“press Ctrl+B”的时候快速按住“Ctrl+B”进入bootroom菜单

System is starting...

Press Ctrl+D to access BASIC-BOOTWARE MENU

Booting Normal Extend BootWare

The Extend BootWare is self-decompressing.....Done!

BootWare Validating...

Press **Ctrl+B** to enter extended boot menu...

BootWare password: Not required. Please press Enter to continue.

Password recovery capability is enabled.

Note: The current operating device is flash

Enter < Storage Device Operation > to select device.

按住“Ctrl+B”进入如下菜单。选择“<6> Skip Current System Configuration”跳过当前配置启动,不同设备可能不是数字6,

```
=====<EXTEND-BOOTWARE MENU>=====
===
|<1> Boot System
|<2> Enter Serial SubMenu
|<3> Enter Ethernet SubMenu
|<4> File Control
|<5> Restore to Factory Default Configuration
|<6> Skip Current System Configuration
|<7> BootWare Operation Menu
|<8> Clear Super Password
|<9> Storage Device Operation
|<0> Reboot
=====
```

Ctrl+Z: Access EXTEND-ASSISTANT MENU

Ctrl+F: Format File System

Enter your choice(0-9): 6

Flag Set Success.

然后输入0重启设备

===== <EXTEND-BOOTWARE MENU> =====

==

|<1> Boot System

|

|<2> Enter Serial SubMenu

|

|<3> Enter Ethernet SubMenu

|

|<4> File Control

|