

组网及说明


1.1 适用产品系列

本案例适用于如S5500V2-34S-EI、S5500V2-28F-SI、S5530F-EI-D、S5560-54C-EI、S5560X-54C-PWR-EI、S5820V2-52Q、S5820V2-52QF-H3等S5500V2、S55X0、S58X0V2系列的交换机。

1.2 配置需求

用户已经成功登录到了设备上，并希望将当前设备作为SSH客户端登录到其他设备上进行操作。

2 组网图



配置步骤

3.1 设备作为SSH客户端设置

```

#修改客户端的系统名称为SWA
[H3C]sysname SWA
#配置VLAN虚接口Vlan-interface 1的IP地址为192.168.1.1，此地址作为客户端登录到SSH服务器时所使用的本地地址。
[SWA]interface Vlan-interface 1
[SWA-Vlan-interface1]ip address 192.168.1.1 255.255.255.0
[SWA-Vlan-interface1]quit
  
```

3.2 验证配置

如果客户端支持首次认证，则可以直接与服务器建立连接。

建立到服务器192.168.1.2的SSH连接。

```

<SWA>ssh2 192.168.1.2
Username: client001
Trying 192.168.1.2 ...
Press CTRL+K to abort
Connected to 192.168.1.2 ...
The Server is not authenticated. Continue? [Y/N]:y
Do you want to save the server public key? [Y/N]:n
Enter password:
  
```

输入正确的密码之后，即可成功登录到Switch B上。

```

*****
* Copyright (c) 2004-2013 Hangzhou H3C Tech. Co., Ltd. All rights reserved. *
* Without the owner's prior written consent, *
* no decompiling or reverse-engineering shall be allowed. *
*****
  
```

<SWB>

如果客户端不支持首次认证，则需要进行如下配置。

配置客户端对服务器不进行首次认证。

```

[SWA] undo ssh client first-time
# 在客户端配置SSH服务器端的主机公钥。在公钥编辑视图输入服务器端的主机公钥，即在服务器端SWB通过display public-key local dsa public命令显示的公钥内容。
[SWA] public-key peer key1
[SWA] public-key-code begin
[SWA-pkey-key-
code]308201B73082012C06072A8648CE3804013082011F02818100D757262C4584C44C211F18BD9
6E5F0
  
```

```
[SWA-pkey-key-
code]61C4F0A423F7FE6B6B85B34CEF72CE14A0D3A5222FE08CECE65BE6C265854889DC1EDB
D13EC8B274
[SWA-pkey-key-
code]DA9F75BA26CCB987723602787E922BA84421F22C3C89CB9B06FD60FE01941DDD77FE6B12
893DA76E
[SWA-pkey-key-
code]EBC1D128D97F0678D7722B5341C8506F358214B16A2FAC4B368950387811C7DA33021500C
773218C
[SWA-pkey-key-
code]737EC8EE993B4F2DED30F48EDACE915F0281810082269009E14EC474BAF2932E69D3B1F1
8517AD95
[SWA-pkey-key-
code]94184CCDFCEAE96EC4D5EF93133E84B47093C52B20CD35D02492B3959EC6499625BC4FA
5082E22C5
[SWA-pkey-key-
code]B374E16DD00132CE71B020217091AC717B612391C76C1FB2E88317C1BD8171D41ECB83E2
10C03CC9
[SWA-pkey-key-
code]B32E810561C21621C73D6DAAC028F4B1585DA7F42519718CC9B09EEF0381840002818000A
F995917
[SWA-pkey-key-
code]E1E570A3F6B1C2411948B3B4FFA256699B3BF871221CC9C5DF257523777D033BEE77FC378
145F2AD
[SWA-pkey-key-
code]D716D7DB9FCABB4ADBFB6FB4FDB0CA25C761B308EF53009F7101F7C62621216D5A572C37
9A32AC290
[SWA-pkey-key-
code]E55B394A217DA38B65B77F0185C8DB8095522D1EF044B465E8716261214A5A3B493E866991
113B2D
[SWA -pkey-key-code]485348
[SWA -pkey-key-code] public-key-code end
[SWA -pkey-public-key] peer-public-key end
# 指定服务器192.168.1.2对应的主机公钥名称为key1。
[SWA] ssh client authentication server 192.168.1.2 assign publickey key1
[SWA] quit
# 建立到服务器192.168.1.2的SSH连接。
< SWA > ssh2 192.168.1.2
Username: client001
Trying 192.168.1.2 ...
Press CTRL+K to abort
Connected to 192.168.1.2...
Enter password:
输入正确的密码之后, 即可成功登录到Switch B上。
```

配置关键点