

问题描述

MSR路由器基础版和标准版怎么区分?

解决方法

1. 区分基础版和标准版的设备

区分基础版和标准版的分销MSR路由器有: MSR2020, MSR2021, MSR3016.

2. 判断设备基础版和标准版的方法

任意视图下通过命令display version查看

<H3C>display version

H3C Comware Platform Software

Comware software, Version 5.20, Release 2105, Standard----标准版

Copyright(c) 2004-2010 Hangzhou H3C Technology Co., Ltd. All rights reserved.

H3C MSR20-20 uptime is 0 week, 0 day, 6 hours, 27 minutes

Last reboot 2011/06/09 10:00:02

System returned to ROM By Power-up.

<H3C>display version

H3C Comware Platform Software

Comware software, Version 5.20, Release 2105, Basic----基础版

Copyright(c) 2004-2010 Hangzhou H3C Technology Co., Ltd. All rights reserved.

H3C MSR20-20 uptime is 0 week, 0 day, 6 hours, 27 minutes

Last reboot 2011/06/08 12:00:02

System returned to ROM By Power-up.

1. 基础版和标准版的区别

1. 基础版是简化版本, 基础版不需要注册;
2. 标准版是完全版本, 支持用户手册上的完整功能;
3. 出厂版本都是基础版, 标准版需要注册License;
若购买的是标准版软件, 包含License的授权书会随设备发货;
1. 若购买的是基础版软件, 升级到标准版需要另外购买License;
1. 基础版和标准版对于相关协议和特性支持情况的详细信息请参见链接[http://www.h3c.com.cn/Service/Document_Center/Routers/Catalog/MSR/MSR_50/Configure/Operation_Manual/H3C_MSR_CG-Release_2104\(V1.10\)/00/201311/803303_30005_0.htm](http://www.h3c.com.cn/Service/Document_Center/Routers/Catalog/MSR/MSR_50/Configure/Operation_Manual/H3C_MSR_CG-Release_2104(V1.10)/00/201311/803303_30005_0.htm)