



## IX3000产品如何升级BMC

其它功能

李舒丹

2008-11-26 发表

### IX3000产品如何升级BMC

#### 一、组网需求:

无

#### 二、组网图:

无

#### 三、配置步骤:

此案例适用于IX3000-V6.00 Build6083E01版本及以前版本。

##### 1、硬件连接

PC机网口连接管理口，配置PC网口IP地址与管理FE在同一个网段，使用Putty等工具通过管理FE口登录Linux系统进行下面的升级，并拔掉连接在XEON和IOP上的串口线

。

##### 2、升级过程

```
[root@xu-20 bmc]# cd /usr/local/H3C/bmc/
[root@xu-20 bmc]# ls
bmcufu-ix3000 IX3000-MCUA02-R0004P01.HEX updatebmc.sh
[root@xu-20 bmc]# chmod +x bmcufu-ix3000
[root@xu-20 bmc]# chmod +x updatebmc.sh
[root@xu-20 bmc]# ./updatebmc.sh IX3000-MCUA02-R0004P01.HEX
```

```
=====
Warning: you are about to do a dangerous operation !!!
      neostor service will be stoped
please assure power suply and do not turn of the device !!!
=====
```

```
Are you want to upgrade BMC (Y)es/(N)o? [N]y
```

出现如下信息说明升级成功

```
Download Finished... taking 34 seconds
```

```
Now launching the brand new code...
```

```
# Set SP2 to SI2 for COM2
```

```
BMC upgrade finished, system maybe not usable before reboot!!!
```

#### 四、配置关键点:

BMC升级失败会导致系统无法正常启动，并且现场无法恢复。请确认当前的BMC版本，并根据版本发布说明书的描述确认升级的必要性。如果出现BMC升级失败，请不要断电，也不要重启系统，请立即联系H3C技术支持二线，一旦断电系统将无法启动。