

问题描述

MSR50电源状态

解决方法

MSR50电源状态:

模块0不在位

```
[H3C]display power
Power 0 State: Absent
Power 1 State: Normal
```

模块0在位上电没打开电源开关

```
[H3C]display power
Power 0 State: Fault
Power 1 State: Normal
Power 2 State: Absent
Power 3 State: Absent
```

模块0在位正常运行

```
[H3C]display power
Power 0 State: Normal
Power 1 State: Normal
Power 2 State: Absent
Power 3 State: Absent
```

模块0在位没插电源线

```
[H3C-hidecmd]_display power verbose
Power      Type      State
0          AC/DC    Error
1          AC/DC    Normal
2          Internal POE Absent
3          External POE Absent
```

模块0在位插了电源线

```
[H3C-hidecmd]_display power verbose
Power      Type      State
0          AC/DC    Normal
1          AC/DC    Normal
2          Internal POE Absent
3          External POE Absent
```

说明:

- 1、电源2和电源3就是_display power ver中显示的internal poe和external poe
- 2、MSR50的POE电源有两个输入，一个是交流的500W，是internal poe；另一个是直流的1000W RP S电源，是external poe。
- 3、电源的状态只有3种：absent（不在位），normal（在位并且已经上电），Error（在位，没有上电或者故障），其他状态区分不出来。