

知 msrmsr3600-28如何做vlan配置

VLAN zhiliao_47490 2018-01-02 发表

问题描述

msrmsr3600-28如何做vlan配置

解决方法

全局配置, 进入

```
<H3C>sy
```

```
System View: return to User View with Ctrl+Z.
```

```
[H3C]vl [H3C]vlan 10
```

```
[H3C-vlan10]int g 1/0/1
```

```
[H3C-GigabitEthernet1/0/1]port link-type trunk
```

```
port link-type trunk
```

```
port trunk permit vlan 1 port trunk permit vlan 100 200 555 1001
```

```
port trunk pvid vlan 1001 #
```

答案来自于 [刀锋之影](#)