

知 V5 AC如何给无线终端打双层VLAN 标签

VLAN 肖倩艳 2017-09-22 发表

Q: V5 AC如何给无线终端打双层VLAN 标签?

A: 配置过程如下

```
<Sysname> system-view
```

```
[Sysname]vlan 10 20
```

```
[Sysname] wlan ap ap3 model WA3628i-AGN
```

```
[Sysname-wlan-ap-ap3] radio 1
```

```
[Sysname-wlan-ap-ap3-radio-1] service-template 1 vlan-id 10 20
```

其中vlan10是外层标签 vlan20是内层标签