



LTE-FI产品4G网络如何配置APN

wlan接入

樊昊

2015-07-28 发表

Cellular口下执行profile create命令。例：`[LA4320-Cellular-Ethernet1/0/1]profile create 1 static ctn et authentication-mode chap user ctnet@mycdma.cn password vnet.mobi`