
```
root@scm:~:Debug> #-----powercycle all the DEs-----#
```

```
root@scm:~:Debug> #-----reboot the SC-----#
```

```
root@scm:~:Debug> reboot
```

此时将所有DE均下电后上电，重启SCM。

第五步：SCM重启完成后，开始域配置状态下，记住配置域名和原来的域相同。完成域配置后输入新的密码，这样原来域的信息就全部回来了：

```
Do you wish to configure a Realm on this node? (Yes|No|Quit) [No]: yes
```

```
Waiting for proper controller state: Done.
```

The following sections will ask for a Realm name, a DNS domain and a Realm Management IP address. It is strongly suggested that Realm name map to the Realm Management IP address in your DNS. That is, if the realm name is myrealm, the DNS domain is acme.com and the Realm Management IP Address is 10.20.30.40, we suggest that the host myrealm.acme.com have the IP address 10.20.30.40 in your DNS.

```
Enter the Realm Name (ex. myrealm) [Not Configured]: realm202
```

第六步：将其余SCM连接好后配置网络地址加入已恢复的域。