

### NE16E/08E/05系列路由器配置文件的保存路径说明

NE16E/08E/05系列路由器由于存储介质既有硬盘 (hda1) , 也有闪存 (flash) , 配置文件缺省到底是保存在硬盘中还是闪存中呢? 要是当前目录在硬盘下, 敲save命令的话, 它会自动更新放在闪存目录下的配置文件吗? 还是另外建一个新的配置文件? 结论如下, 在系统或者用户视图下, 敲display startup命令:

(1) 如果Startup saved-configuration file后边指定的文件为NULL或者已经被删除, 则在用户视图下第一次执行save命令时, 会提示输入保存文件名, 如果文件名前不加绝对路径符的话, 缺省保存在flash中; 如果输入“hda1:/文件名”, 则保存在硬盘中。并且自动把Startup saved-configuration file和Next startup saved-configuration file设为刚刚保存的文件。

(2) 如果Startup saved-configuration file后边指定的文件存在, 则不管在硬盘还是闪存目录下执行save命令, 都会直接更新Startup saved-configuration file后边指定的文件, 并且不会提示输入保存文件名。

#### 附录: 具体实验现象

系统加载完成后, 先看一下启动文件及配置文件信息

```
<Quidway>display startup
```

```
MainBoard:
```

```
Configed startup system software:   hda1:/1726.cc
Startup system software:             hda1:/ne05.cc
Next startup system software:        hda1:/1726.cc
Startup saved-configuration file:    flash:/1.zip
Next startup saved-configuration file: flash:/1.zip
```

当启动文件已经被不存在时,

```
<Quidway>dir
```

```
Directory of flash:/
```

```
0 -rw- 10859 Dec 29 2006 09:09:13 paf.txt
1 -rw- 5426 Dec 29 2006 09:09:33 license.txt
2 -rw- 12274 Dec 14 2002 06:17:37 paf.txt.bak
3 -rw- 4 Jan 19 2007 10:24:45 snmpboots
4 -rw- 1448 Jan 09 2007 15:43:28 test.cfg
```

```
7493 KB total (7451 KB free)
```

可以看到flash:/1.zip已经被删除了, 这时候进行保存操作

```
<Quidway>save
```

```
The router configurations will be written to the device.
```

```
Are you sure?[Y/N]y
```

```
Please input the file name(*.cfg,*.zip)[vrpcfg.zip]:2.cfg
```

```
Now saving current configuration to the device.
```

```
Please wait for a while...
```

会提示敲入保存文件名, 保存后, 可以看到保存在flash里边

```
<Quidway>dir
```

```
Directory of flash:/
```

```
0 -rw- 10859 Dec 29 2006 09:09:13 paf.txt
1 -rw- 5426 Dec 29 2006 09:09:33 license.txt
2 -rw- 12274 Dec 14 2002 06:17:37 paf.txt.bak
3 -rw- 4 Jan 19 2007 10:24:45 snmpboots
4 -rw- 1448 Jan 09 2007 15:43:28 test.cfg
5 -rw- 590 Jan 24 2007 16:13:56 2.cfg
```

```
7493 KB total (7451 KB free)
```

这时候启动文件信息也自动变化, 可以看到配置文件信息已经修改

```
<Quidway>dis startup
```

```
MainBoard:
```

```
Configed startup system software:   hda1:/1726.cc
Startup system software:             hda1:/ne05.cc
Next startup system software:        hda1:/1726.cc
```

```
Startup saved-configuration file: flash:/2.cfg
Next startup saved-configuration file: flash:/2.cfg
要是清空配置文件信息了
<Quidway>reset saved-configuration
This will delete the configuration in the flash memory.
The router configurations will be erased to reconfigure.
Are you sure?[Y/N]y
Now clearing the configuration in the device.
Please wait for a while...
<Quidway>display startup
MainBoard:
Configured startup system software: hda1:/1726.cc
Startup system software: hda1:/ne05.cc
Next startup system software: hda1:/1726.cc
Startup saved-configuration file: NULL
Next startup saved-configuration file: flash:/2.zip
再执行save操作
<Quidway>save
The router configurations will be written to the device.
Are you sure?[Y/N]y
Please input the file name(*.cfg,*.zip)[vrpcfg.zip]:hda1:/3.cfg
Now saving current configuration to the device.
Please wait for a while...
.....
Saved the current config to mainboard device successfully
<Quidway>display startup
MainBoard:
Configured startup system software: hda1:/1726.cc
Startup system software: hda1:/ne05.cc
Next startup system software: hda1:/1726.cc
Startup saved-configuration file: hda1:/3.cfg
Next startup saved-configuration file: hda1:/3.cfg
<Quidway>dir
Directory of hda1:/
 0 -rw- 121696 Jan 17 2002 08:47:10 matnlog.dat
 1 drw- - Jan 14 2002 05:38:44 logfile
 2 -rw- 10681500 Jun 16 2000 07:08:52 ne05.cc
 3 -rw- 7120036 May 14 2001 09:27:00 1717.cc
 4 -rw- 10102748 Oct 10 2001 10:02:44 ne05-ne08e-ne16e-vrp330-0506.08.cc
 5 -rw- 28 Jan 14 2002 05:53:06 private-data.txt
 6 -rw- 7178964 Oct 12 2001 04:43:54 1724.cc
 7 -rw- 10317588 Nov 22 2001 00:57:12 ne05-ne08e-ne16e-vrp330-0519.cc
 8 -rw- 14694354 Nov 26 2001 06:34:00 ne05-ne08e-ne16e-vrp510-1241.02.cc
 9 -rw- 14463428 Jan 14 2002 00:04:44 vrp510-124103.cc
10 -rw- 0 Jan 14 2002 00:29:26 ntuser.dat
11 -rw- 7120036 Jan 17 2002 08:37:24 8070-1717.01.cc
12 -rw- 7233020 Jan 17 2002 08:48:48 8070-1728.cc
13 drw- - Dec 31 2002 07:00:52 backup
14 -rw- 590 Jan 24 2007 16:38:20 3.cfg
19525472 KB total (19417616 KB free)
要是配置文件存在并且没有被清空的情况下, 执行save命令
<Quidway>save
The router configurations will be written to the device.
Are you sure?[Y/N]y
Now saving current configuration to the device.
Please wait for a while...
.....
Saved the current config to mainboard device successfully
可以看到并不会提示输入存储文件名, 而是直接更新在display startup中看到的Startup saved-configuration file后边指定的文件, 与在哪个目录下操作没有关系。
```