

组网及说明

本案例为S1850 IP+MAC绑定的方法

S1850版本信息如下:

H3C Comware Platform Software

Comware Software, Version 5.20.99, Release 1102

Copyright (c) 2004-2017 New H3C Technologies Co., Ltd. All rights reserved.

H3C S1850-28P uptime is 0 week, 5 days, 6 hours, 8 minutes

H3C S1850-28P

128M bytes DRAM

32M bytes Flash Memory

Config Register points to Flash

Hardware Version is Ver.A

Bootrom Version is 102

[SubSlot 0] 24GE+4SFP Hardware Version is Ver.A

配置步骤

IP+MAC方法一:

在全局模式使用arp static方式进行绑定, 命令如下:

```
arp static 1.1.1.1 0023-24a1-0605
```

IP+MAC方法二:

进入接口使用arp filter方式进行绑定, 命令如下:

```
int GigabitEthernet 1/0/1
```

```
arp filter binding 1.1.1.1 0023-24a1-0605
```

IP+MAC方法三:

进入接口使用动态绑定表项的方式进行绑定, 命令如下:

```
int GigabitEthernet 1/0/1
```

```
ip source binding ip-address 1.1.1.1 mac-address 0023-24a1-0605
```

```
ip verify source ip-address mac-address
```

IP+MAC方法四:

如果本设备配置为DHCP服务器, 且要实现IP+MAC的静态绑定, 命令如下:

```
dhcp enable
```

```
dhcp server ip-pool 123
```

```
static-bind ip-address 1.1.1.1 24
```

```
static-bind mac-address 0023-24a1-0605
```

配置关键点