

## 知 How does V7 AC enable AP remote Telnet login function.

Wireless 周天 2020-05-20 Published

### Problem Description

Q: How does V7 AC enable AP remote Telnet login function?

### Solution

A: First check which ap is required to log in

Versions before R5119P12 are enabled by default. Versions starting with R5119P12 need to open the following commands in the probe view:

```
[AC] probe
```

```
[AC-probe] wlan ap-execute AP name exec-control enable
```

AP's default login password is h3capadmin