

知 S6520与华为5720对接NTP典型组网配置案例

NTP 韦家宁 2020-05-30 发表

组网及说明

S6520与华为5720对接NTP典型组网配置，其中S6520为时钟源，华为5720为客户端

S6520版本信息如下：

H3C Comware Software, Version 7.1.070, Release 1110P02

Copyright (c) 2004-2018 New H3C Technologies Co., Ltd. All rights reserved.

H3C S6520X-54QC-EI uptime is 31 weeks, 3 days, 21 hours, 12 minutes

Last reboot reason : Cold reboot

Boot image: flash:/s6520x-cmw710-boot-r1110p02.bin

Boot image version: 7.1.070, Release 1110P02

Compiled Aug 14 2018 11:00:00

System image: flash:/s6520x-cmw710-system-r1110p02.bin

System image version: 7.1.070, Release 1110P02

Compiled Aug 14 2018 11:00:00

华为5720版本信息如下：

Huawei Versatile Routing Platform Software

VRP (R) software, Version 5.170 (S5720 V200R010C00SPC600)

Copyright (C) 2000-2016 HUAWEI TECH CO., LTD

HUAWEI S5720-56C-EI-AC Routing Switch uptime is 98 weeks, 2 days, 13 hours, 51 minutes

ES5D2T52C002 0(Master) : uptime is 98 weeks, 2 days, 13 hours, 50 minutes

DDR Memory Size : 2048 M bytes

FLASH Memory Size : 344 M bytes

Pcb Version : VER.C

BootROM Version : 020a.0001

BootLoad Version : 020a.0001

CPLD Version : 010c

Software Version : VRP (R) Software, Version 5.170 (V200R010C00SPC600)

PWR1 information

Pcb Version : PWR VER.B

PWR2 information

Pcb Version : PWR VER.B

FAN1 information

Pcb Version : NA

配置步骤

S6520 NTP时钟源配置信息如下：

clock protocol none

ntp-service enable

ntp-service refclock-master 2

interface Vlan-interface100

description YunWeiGuanLi

ip address 10.190.8.1 255.255.255.192

quit

华为5720 NTP配置如下：

ntp-service server disable

ntp-service ipv6 server disable

ntp-service unicast-server 10.190.8.1

S6520查看NTP显示信息：

dis ntp sessions

source	reference	stra	reach	poll	now	offset	delay	disper
--------	-----------	------	-------	------	-----	--------	-------	--------

[25]10.190.8.252	LOCL		1	255	64	51	-28825	0.9002 18.218
------------------	------	--	---	-----	----	----	--------	---------------

[12345]LOCAL(0) LOCL 1 255 64 42 0.0000 0.0000 0.9155
Notes: 1 source(master), 2 source(peer), 3 selected, 4 candidate, 5 configured.
Total sessions: 2

dis ntp status

Clock status: synchronized
Clock stratum: 2
System peer: LOCAL(0)
Local mode: client
Reference clock ID: 127.127.1.0
Leap indicator: 00
Clock jitter: 0.000000 s
Stability: 0.000 pps
Clock precision: 2⁻²¹
Root delay: 0.00000 ms
Root dispersion: 10.98633 ms
Reference time: e27ced67.56daf74f Sat, May 30 2020 14:34:15.339
System poll interval: 64 s

华为5720查看NTP显示信息：

dis ntp sessions

clock source: 10.190.8.1
clock stratum: 2
clock status: configured, master, sane, valid
reference clock ID: LOCAL(0)
reach: 177
current poll: 64
now: 0
offset: -0.6858 ms
delay: 3.69 ms
disper: 4.88 ms

dis ntp status

clock status: synchronized
clock stratum: 3
reference clock ID: 10.190.8.1
nominal frequency: 100.0000 Hz
actual frequency: 100.0000 Hz
clock precision: 2⁻¹⁶
clock offset: -10.4463 ms
root delay: 3.69 ms
root dispersion: 7216.57 ms
peer dispersion: 11.58 ms
reference time: 14:32:52.204 UTC May 30 2020(E27CED14.344AE85B)
synchronization state: clock set but frequency not determined

配置关键点

- 1、 确保时钟源和时钟客户端路由可达。
- 2、 时钟源及时钟客户端都需要开启NTP功能。
- 3、 时钟客户端指定时钟源为NTP服务器。
- 4、 时钟源所在的设备配置为时钟源。