

Does fat AP enable Layer 2 isolation by default?

Wireless 龚训杰 2020-08-19 Published

Problem Description

Does fat AP enable Layer 2 isolation by default?

Fat APs enable Layer 2 isolation by default. The related commands are different from thin APs. You n $eed \ to \ disable \ them \ with \ the \ command \ [sys] \ undo \ wlan-client-isolation \ enable$