



# The iPhone cannot recognize the Chinese SSID.

Wireless

龚训杰

2020-08-24 Published

## Problem Description

The iPhone cannot recognize the Chinese SSID.

## Solution

(1) The default character encoding method of SecureCRT itself is GB2312. Log in to AC through CRT , and configure the Chinese SSID on AC to be the encoding of GB2312, but Apple terminal only supports UTF-8 encoding for Chinese, so you need to change the encoding on AC the way.

(2) Use CRT version 7.0 or higher, change the encoding format to UTF-8, and reconfigure the Chinese SSID.