



How to change the AP LED mode

Wireless

龚训杰

2020-08-28 Published

Problem Description

How to change the AP LED mode

Solution

```
wlan ap uap model UAP300-S1
```

```
[H3C-wlan-ap-uap]led-mode ?
```

always-on All LEDs are always on

awake Only the power LED flashes once every minute

normal Default mode for LEDs

quiet All LEDs are always off