



How to adjust the AP's transmit power?

Wireless

龚训杰

2020-08-28 Published

Problem Description

How to adjust the AP's transmit power?

Solution

Fat AP setting command:

```
[Sysname] interface wlan-radio 1/0/1
```

```
[Sysname-WLAN-Radio1/0/1] max-power 5
```

Fit AP setting command:

```
# Configure the maximum transmission power of the radio to 5.
```

```
<Sysname> system-view
```

```
[Sysname] wlan ap ap3 model WA2100
```

```
[Sysname-wlan-ap-ap3] radio 1
```

```
[Sysname-wlan-ap-ap3-radio-1] max-power 5
```