

知 How to adjust the AP's transmit power?

Wireless 龚训杰 2020-08-28 Published

Problem Description

How to adjust the AP's transmit power?

Solution

Fat AP setting command:

```
[Sysname] interface wlan-radio 1/0/1  
[Sysname-WLAN-Radio1/0/1] max-power 5
```

Fit AP setting command:

```
# Configure the maximum transmission power of the radio to 5.  
<Sysname> system-view  
[Sysname] wlan ap ap3 model WA2100  
[Sysname-wlan-ap-ap3] radio 1  
[Sysname-wlan-ap-ap3-radio-1] max-power 5
```