

Can the downstream port of the Terminator be connected to a PC?

Wireless 龚训杰 2020-08-28 Published

Can the downstream port of the Terminator be connected to a PC?

No! If the downstream port of the main body is directly connected to the PC, it is easy to burn the PC $network\ card.\ If\ you\ really\ need\ to\ connect\ to\ the\ PC\ for\ testing,\ you\ can\ turn\ off\ the\ PoE\ function\ of\ t$ he downstream port of the main body before connecting to the PC. The command to turn off the pow er supply function of the main body's downstream port is as follows:

[WX2510H-wlan-ap-1020] \pmb{poe} wtu-port 2 disable //2 is the downstream port number