

组网及说明

为了确保设备的TELNET安全登陆管理，需对TELNET进行登录限制。

S10510的版本信息如下：

H3C Comware Software, Version 7.1.070, Release 7536P05

Copyright (c) 2004-2017 New H3C Technologies Co., Ltd. All rights reserved.

H3C S10510 uptime is 92 weeks, 2 days, 4 hours, 3 minutes

Last reboot reason : USER reboot

配置步骤

配置ACL对TELNET进行登录限制：

1、创建管理员账号，并赋予最高权限，仅允许TELNET登录

```
[H3C]local-user admin
```

```
[H3C-luser-manage-admin]password simple admin
```

```
[H3C-luser-manage-admin]service-type telnet
```

```
[H3C-luser-manage-admin]authorization-attribute user-role network-admin
```

```
[H3C-luser-manage-admin]quit
```

2、开启TELNET功能

```
[H3C]telnet server enable
```

3、在VTY调用本地用户登录

```
[H3C]line vty 0 4
```

```
[H3C-line-vty0-4]authentication-mode scheme
```

```
[H3C-line-vty0-4]protocol inbound telnet
```

```
[H3C-line-vty0-4]quit
```

4、创建ACL，仅允许管理员IP 192.168.124.7通过TELNET登录交换机，其他IP无法登陆

```
[H3C]acl basic 2000
```

```
[H3C-acl-ipv4-basic-2000]rule 0 permit source 192.168.124.7 0
```

```
[H3C-acl-ipv4-basic-2000]quit
```

```
[H3C]telnet server acl 2000
```

配置关键点

附件下载：[S10510 telnet登陆限制案例.zip](#)