

## Problem Description

How does the switch supply power to the AP

Solution

Enter interface view:

POE Enable