

知 How does a fit AP select a channel when starting up? Can the fit AP change its channel while operating?

Wireless 龚训杰 2020-09-27 Published

Problem Description

How does a fit AP select a channel when starting up? Can the fit AP change its channel while operating?

Solution

By default, a fit AP automatically selects a channel when starting up. The selected channel does not change when the AP is operating unless radar signals are detected on the working channel or DFS is configured.