



How can I associate fit APs with an AC?

Wireless

龚训杰

2020-09-27 Published

Problem Description

How can I associate fit APs with an AC?

Solution

You can create manual APs or enable auto AP on the AC.

If auto AP is disabled, only APs with manual AP configuration can be associated with the AC.

If auto AP is enabled, APs can be associated with the AC without manual AP configuration. The AC names auto APs by their MAC addresses. This feature simplifies configuration when you deploy a large number of APs in a WLAN.

wlan auto-ap enable

wlan auto-persistent enable