



How can I connect a fit AP to an AC physically?

Wireless

龚训杰

2020-09-27 Published

Problem Description

How can I connect a fit AP to an AC physically?

Solution

You can connect an AP to an AC directly or over a Layer 2 network or a Layer 3 network, as long as they can reach each other.