

How does ONEStor check the software version in the system background?



Cloud Computing 崔敬渊 2020-10-12 Published

Problem Description

Sometimes the ONEStor management interface cannot log in due to license expired and other reaso ns. How to check the ONEStor software version at this time?

You can execute cat /etc/onestor_external_version in the system background of any node in the cl uster.