

M How to view AC version information?

Wireless 河然·吐尔生别克 2020-12-11 Published

Problem Description

How to view AC version information?

Use the command: display version If you need to view the detailed version Use command : _display version