

(M) Why is the AC serial number on Oasis not the real serial number of the devi ce?

Wireless 余煌 2020-12-18 Published

null

If the devices are stacked, the AC serial numbers displayed by the active and standby ACs are the sa me virtual serial number, and the serial number suffix is randomly generated. In this way, both the ma ster and slave use a serial number to treat them as a whole, so that data will not be lost when switchin g. If you want to check the real serial number of AC. You can click into AC basic information to view.