



125X buffer告警各参数具体含义

其他硬件相关

李敏

2022-03-16 发表

问题描述

lease check slot 4 Buffer! The buffer(5146, 557055, 530739) of chip 1 on slot 4 to port FGE4/0/39 is used up to 90%。

客户关心Buffer中数值具体含义

解决方法

buffer(5146, 557055, 530739)

队列号, 该队列最大缓存, 该队列当前缓存

此数值大小一般不需要关注

| | |
|------|---|
| 日志内容 | WARNING: Please check slot %d Buffer! The buffer(%d, %d, %d) of chip %d on slot %d to port %s is used up to %d%%. The CoS field is %d. |
| 参数解释 | \$1: 槽位号 \$2: uiQid+uiCos \$3: uiMaxQSize \$4: uiCngQSize \$5: 芯片号 \$6: 本板槽位号 \$7: 端口名称 \$8: 队列占用深度 \$9: 队列cos id |
| 日志等级 | 2 |
| 举例 | WARNING: Please check slot 5 Buffer! The buffer(%d, %d, %d) of chip 0 on slot 5 to port %s is used up to %90. The CoS field is 2. |
| 日志说明 | 端口对应的buffer队列占用过高 |
| 处理建议 | 请确认是否存在流量超带宽情况 |

