

MSR系列路由器如何同时使用GTS和CBQ

接口下直接配置的gts产生的拥塞无法被CBQ直接感知到，可以采用两种方式解决

(1) 配置lr:

接口下qos lr cir xxx

xxx为期望对接口进行限制的速率，单位为Kbps

(2) 配置嵌套策略:

父策略中配置gts

```
traffic behavior father
```

```
gts cir xxx cbs xxxx
```

```
traffic-policy Nest
```

```
#
```

```
qos policy Nest
```

```
classifier traffic1 behavior behavior1
```

```
classifier traffic2 behavior behavior2
```

```
qos policy father
```

```
classifier default-class behavior father
```