

知 S7000/S7500E/10500系列交换机Console密码忘记处理方法

console

贾璧羽

2022-08-09 发表

配置步骤

V7交换机Console密码忘记处理方法

目录

[V7交换机Console密码忘记处理方法](#)

[1 配置需求或说明](#)

[1.1 适用产品系列](#)

[1.2 配置需求及实现的效果](#)

[2 组网图](#)

[3 配置步骤](#)

[3.1 进入bootroom菜单清除Console密码](#)

[3.2 如果不需要之前的配置信息的话](#)

[3.3 如果需要之前的配置信息的话](#)

1 配置需求或说明

1.1 适用产品系列

本案例适用于如 本案例适用于如S7006、S7503E、S7506E、S7606、S10510、S10508等S7000、S7500E、S10508等S7000、S7500E、S10500系列，且软件版本是V7的交等的V7交换机，V5、V7交换机具体分类及型号可以参考“1.1 Comware V5、V7平台交换机分类说明”。

1.2 配置需求及实现的效果

清除Console密码，恢复出厂

2 组网图

无

3 配置步骤

3.1 进入bootroom菜单清除Console密码

通过conlse线和crt软件连接并登陆设备，然后把设备断电重启。控制台上会打印如下信息，当出现“press Ctrl+B”的时候快速按住“Ctrl+B”进入botroom菜单

System is starting...

Press Ctrl+D to access BASIC-BOOTWARE MENU

Booting Normal Extend BootWare

The Extend BootWare is self-decompressing.....Done!

BootWare Validating...

Press **Ctrl+B** to enter extended boot menu...

BotWare password: Not required. Please press Enter to continue.

Password recovery capability is enabled.

Note: The current operating device is flash

Enter < Storage Device Operation > to select device.

按住“Ctrl+B”进入如下菜单。选择“<6> Skip Current System Configuration”跳过当前配置启动,不同设备可能不是数字6,

=====<EXTEND-BOOTWARE MENU>=====

===

|<1> Boot System |

|<2> Enter Serial SubMenu |

|<3> Enter Ethernet SubMenu |

|<4> File Control |

|<5> Restore to Factory Default Configuration |

|<6> Skip Current System Configuration |

|<7> BootWare Operation Menu |

|<8> Clear Super Password |

|<9> Storage Device Operation |

|<0> Reboot |

=====

Ctrl+Z: Access EXTEND-ASSISTANT MENU

Ctrl+F: Format File System

Enter your choice(0-9): 6

Flag Set Success.

然后输入0重启设备

=====<EXTEND-BOOTWARE MENU>=====

===

<1> Boot System		
<2> Enter Serial SubMenu		
<3> Enter Ethernet SubMenu		
<4> File Control		
<5> Restore to Factory Default Configuration		