



# H3C服务器安装系统常用驱动导航

Windows系统安装

驱动安装升级

江金荣

2022-12-04 发表

## 问题描述

H3C服务器安装系统的常用驱动导航

解决方法

G2系列服务器			
<a href="#">R150 G2</a> <a href="#">R170 G2</a> <a href="#">R190 G2</a>	<a href="#">R370 G2</a> <a href="#">R390 G2</a> <a href="#">R390x G2</a>	<a href="#">R4600 G2</a> <a href="#">R4800 G2</a> <a href="#">R4900 G2</a>	<a href="#">R590 G2</a> <a href="#">R690 G2</a> <a href="#">R6600 G2</a> <a href="#">R6800 G2</a>
G3系列服务器			
<a href="#">R2700 G3</a> <a href="#">R2900 G3</a> <a href="#">E3200 G3</a>	<a href="#">R4300 G3</a> <a href="#">R4700 G3</a> <a href="#">R4900 G3</a> <a href="#">R4950 G3 Rome</a>	<a href="#">R5200 G3</a> <a href="#">R5300 G3</a>	<a href="#">R6700 G3</a> <a href="#">R6900 G3</a> <a href="#">R8900 G3</a>
G5系列服务器			
<a href="#">R4300 G5</a> <a href="#">R4700 G5</a> <a href="#">R4900 G5</a> <a href="#">R4950 G5 Milan</a> <a href="#">R4950 G5 Rome</a>	<a href="#">R4930 G5</a>	<a href="#">R5300 G5</a>	<a href="#">R6900 G5</a>
G6系列服务器			
<a href="#">R4700 G6</a>	<a href="#">R4900 G6</a> <a href="#">R4900 G6 Ultra</a> <a href="#">R4950 G6</a>	<a href="#">R6700 G6</a>	

想要了解更多请访问: [服务器运维指南](#)

