

# 知 HPE DL380 Gen9 服务器 安装Windows Server 2008 R2常用驱动

Windows系统安装 驱动安装升级 张帅 2023-05-03 发表

## 问题描述

HPE DL380 Gen9 服务器 安装Windows Server 2008 R2常用驱动

## 解决方法

### 一、适用范围

机型：DL380 Gen9

操作系统：Microsoft Windows Server 2008 R2

### 二、驱动下载

如果想要到官网下载最新驱动请参考如下方法：

<https://zhlibc.hpe.com/zhlibc/zhlibc/1630/>

如果您仍没有找到驱动，可以尝试如下链接，本文章会不定期进行更新，请您参考

驱动类别	当前版本		下载地址
	版本号	发布日期	
板载NC331i网卡	17.4.0.0(B)	2016.10.24	<a href="#">驱动下载</a>
iLO 4 Channel Interface Driver	3.30.0.0	2016.10.24	<a href="#">驱动下载</a>
iLO 4 Management Controller Driver	3.30.0.0	2016.10.24	<a href="#">驱动下载</a>
芯片组	10.1.2.77	2016.10.24	<a href="#">驱动下载</a>
板载显卡	6.12.1.1030(C)	2016.10.21	<a href="#">驱动下载</a>
USB 3.0	4.0.0.36(B)	2016.10.21	<a href="#">驱动下载</a>

点击如上超链接后，可以参考如下图文进行驱动的安装和信息的了解（注：如下图片仅做参考，实际内容以驱动链接打开后显示为准）

点击下方"Installation Instructions"查看驱动的安装方法

[Release Notes](#) [Revision History](#) [Important](#) [Installation Instructions](#) [Fixes](#)

To ensure the integrity of your download, HPE recommends verifying your results with this SHA-256 Checksum value:

85fa024bc5fb5f5aaa31e7f9fad993d8592927f791c69545f2bd2d9152db2797 cp039984.exe

#### Reboot Requirement:

Reboot may be required after installation for updates to take effect and hardware stability to be maintained.

#### Installation:

Place the Smart Component in a temporary directory, then double-click it to run.

Select "Install" to start extracting to a temporary location on the hard drive.

Click the "Install" button to perform the driver installation.

点击下方"Revision History"查看历史版本及修复的相关问题

[Release Notes](#) [Revision History](#) [Important](#) [Installation Instructions](#) [Fixes](#)

#### Version: 4.1.0.0 (9 Sep 2019)

##### Fixes

#### Upgrade Requirement:

**Recommended** - HPE recommends users update to this version at their earliest convenience.

Corrected a potential Windows bugcheck 0x50 (PAGE\_FAULT\_IN\_NONPAGED\_AREA) that could occur if Windows restarts the driver without unloading it.

#### Version: 4.0.0.0 (27 Nov 2018)

##### Enhancements

#### Upgrade Requirement:

**Optional** - Users should update to this version if their system is affected by one of the documented fixes or if there is a desire to utilize any of the enhanced functionality provided by this version.

Aligned system and operating system support with the production Service Pack for ProLiant:

- Removed support for Windows Server 2008 and Windows Server 2008 R2.
- Removed support for iLO 3.
- Removed support for HP ProLiant G7 and HP ProLiant Gen8 systems.

