

如何在CLI下配置HPE 6125G Ethernet Blade Switch 交换机管理地址

尹世伟 2017-08-27 发表

如何在CLI下配置6125交换机管理地址

先OA connect interconnect X的方式连接到6125上然后按一下命令配置

<6125G Blade Switch>system-view

[6125G Blade Switch]interface M-Ethernet 0/0/0

[6125G Blade Switch-M-Ethernet0/0/0]ip address dhcp-alloc

[6125G Blade Switch-M-Ethernet0/0/0]quit

[6125G Blade Switch]save

The current configuration will be written to the device. Are you sure? [Y/N]:y

Please input the file name(*.cfg)[flash:/config.cfg]

(To leave the existing filename unchanged, press the enter key):

flash:/config.cfg exists, overwrite? [Y/N]:

Before pressing ENTER you must choose & # 39;YES& # 39; or & # 39;NO& # 39;[Y/N]:y

Validating file. Please wait....

The current configuration is saved to the active main board successfully.

Configuration is saved to device successfully

配置成功后重新到oa的EBIPA界面配置管理ip即可。