

Cloudos3.0云管理平台如果不同可用域需要公用同一个网络，需要按照以下方法配置，详细看以下配置步骤

1、修改计算节点的出口名称，出口名称两个可用域保持一致
CAS计算节点的出口名字



The screenshot displays the H3C Cloud Operation System interface. The top navigation bar includes the H3C logo, the system name 'H3C 云操作系统', and several menu items: '概览' (Overview), '设备' (Devices), '云资源' (Cloud Resources), '云应用' (Cloud Applications), and '系统' (System). The main content area is divided into two panels. The left panel, titled '基础信息' (Basic Information), shows the '租户名称' (Tenant Name) as 'VLAN'. The right panel, titled '网络出口配置' (Network Exit Configuration), shows a table of network exit configurations. The table has columns for '是否启用' (Whether to Enable), '网络类型' (Network Type), 'VLAN 范围' (VLAN Range), and '生效' (Effective). The table lists three entries: 'wan0/0/25', 'wan0/0/26', and 'wan0/0/27', all with '是否启用' checked and '生效' status '是' (Yes).

4、添加网络，勾选两个可用域，配置相对应的网络

