

组网及说明

1 配置需求或说明

1.1 适用产品系列

本案例适用于如WX1804H、WX2510H、WX3010H、WX3508H、WX5540H等WX18H、WX25H、WX30H、WX35H、WX55H系列的AC。

配置步骤

<H3C>**reset saved-configuration**

The saved configuration file will be erased. Are you sure? [Y/N]:Y //确定删除保存的配置文件

<H3C>**reboot**

Start to check configuration with next startup configuration file, please wait.....DONE!

This command will reboot the device. Current configuration will be lost, save current configuration? [

Y/N]:N //不保存配置

This command will reboot the device. Continue? [Y/N]:Y //继续重启

配置关键点