

AR28/46路由器清除进入console口的密码的方法

可以通过从BOOTROM中选择“忽略配置”启动路由器来获取和重新设备console的密码！

具体操作如下：

第一步:重启路由器，按Ctrl + B进入BOOTROM菜单

```
Starting at 0x1c00000...
*****
*                                     *
*   Quidway Series Routers Boot ROM, V9.07   *
*                                     *
*****

Copyright(C) 1997-2004 by HUAWEI TECH CO., LTD.
Compiled at 18:10:29 , Oct 14 2004.

Testing memory...OK!
128M bytes SDRAM
32768k bytes flash memory
Hardware Version is MTR 1.0
CPLD Version is CPLD 1.0
Press Ctrl-B to enter Boot Menu
Please input Bootrom password: /默认密码为空/
```

Boot Menu:

- 1: Download application program with XMODEM
 - 2: Download application program with NET
 - 3: Set application file type
 - 4: Display applications in Flash
 - 5: Clear application password
 - 6: Start up and ignore configuration
 - 7: Enter debugging environment
 - 8: Boot Rom Operation Menu
 - 9: Do not check the version of the software
 - a: Exit and reboot
- Enter your choice(1-a):

第二步:选择第六项“6: Start up and ignore configuration”，并确认

```
Boot Menu:
1: Download application program with XMODEM
2: Download application program with NET
3: Set application file type
4: Display applications in Flash
5: Clear application password
6: Start up and ignore configuration
7: Enter debugging environment
8: Boot Rom Operation Menu
9: Do not check the version of the software
a: Exit and reboot
Enter your choice(1-a): 6
Start up and ignore configuration, Are you sure?[Y/N]y
Set Succeeds
```

第三步: 选择a项重启系统

```
Boot Menu:
1: Download application program with XMODEM
2: Download application program with NET
3: Set application file type
4: Display applications in Flash
```

```
5: Clear application password
6: Start up and ignore configuration
7: Enter debugging environment
8: Boot Rom Operation Menu
9: Do not check the version of the software
a: Exit and reboot
Enter your choice(1-a): a
Exit and reboot,are you sure?[Y/N]y
Start to reboot...
```

第四步：当系统以空配置起来以后，使用“more config.cfg”查看配置脚本

```
<Quidway>dir
Directory of flash:/

 0 -rw- 5748224 Nov 19 2004 17:23:05  main.bin
 1 -rw- 5746199 Nov 30 2004 14:51:21  v330-0008.bin
 2 -rw- 8650414 Nov 22 2004 12:26:57  system
 3 -rw-   1053 Dec 15 2004 18:46:41  config.cfg
 4 -rw- 8695261 Dec 15 2004 09:59:45  340-0006.bin
```

```
31877 KB total (3706 KB free)
```

```
<Quidway>more config.cfg
sysname RTA
#
FTP server enable
#
local-server nas-ip 127.0.0.1 key huawei
#
domain default enable system
#
radius scheme system
server-type huawei
primary authentication 127.0.0.1 1645
primary accounting 127.0.0.1 1646
user-name-format without-domain
#
domain system
access-limit disable
state active
#
local-user aaa
password cipher ;)<01%^&;YQG=^Q`MAF4<1!!
service-type terminal
level 3
local-user admin
password cipher .J@USE=B,53Q=^Q`MAF4<1!!
service-type telnet terminal
level 3
service-type ftp
#
interface Aux0
async mode flow
link-protocol ppp
#
interface Ethernet0/0
ip address dhcp-alloc
#
interface Serial0/0
clock DTECLK1
link-protocol ppp
ip address ppp-negotiate
#
interface NULL0
#
```

```
user-interface con 0
 authentication-mode scheme
user-interface aux 0
user-interface vty 0 4
 authentication-mode scheme
#
return
```

如果是采用simple方式配置口令，则可以直接显示出密码。

如果是采用cipher方式配置口令，按照以下方法处理：

- 1) 将查看到的配置文件复制保存成一个文本文件。
- 2) 修改该文件中对应帐号的密码“password cipher ;)<01%^&;YGQ=^Q`MAF4<1!!”为类似“password simple aaa”的口令
- 3) 将修改过的脚本，复制粘贴到当前路由器中
- 4) disp cur确认当前配置和以前的配置一致后，save配置后重新启动系统
- 5) 重启后，就可以通过修改过的帐号口令登录系统