

AR28/AR46系列路由器telnet重定向功能的典型配置

AR28/AR46路由器作为串口服务器可以实现telnet重定向功能，具体配置参考如下：

1、异步口配置：

```
physical-mode async
async mode flow
undo detect dsr-dtr
ip address ppp-negotiate
```

2、user-interface tty配置：

```
user-interface tty 18
undo shell
redirect enable
redirect refuse-negotiation
redirect return-deal from-telnet
```