

### S6500交换机如何查看当前运行的版本

可以使用命令display version查看系统当前运行的主机程序版本和Bootrom版本:

```
[Quidway] display version
```

```
Huawei-3Com Versatile Routing Platform Software
```

```
VRP(R) software, Version 3.10, Release 3037 ? 主机软件版本号
```

```
Copyright (c) 2003-2005 Hangzhou Huawei-3Com Tech. Co.,Ltd. All rights reserved.
```

```
Copyright (c) 2000-2003 Huawei Tech. Co.,Ltd. All rights reserved.
```

```
Quidway S6503 uptime is 0 week, 0 day, 1 hour, 44 minutes
```

```
SRPG 0: uptime is 0 weeks,0 days,1 hours,44 minutes
```

```
QuidwayS6500 with 1 MPC8245 Processor
```

```
256M bytes SDRAM
```

```
32768K bytes Flash Memory
```

```
512K bytes NVRAM Memory
```

```
PCB Version : VER.C
```

```
BootROM Version : 510 ? 主控板Bootrom版本号
```

```
CPLD Version : 004
```

```
Second CPLD Ver : 002
```

```
Software Version : S6503-3037 ? 主机软件版本号
```

```
LPU 3: uptime is 0 weeks,0 days,1 hours,41 minutes
```

```
QuidwayS6500 LPU with 1 MPC8245 Processor
```

```
256M bytes SDRAM
```

```
32768K bytes Flash Memory
```

```
0K bytes NVRAM Memory
```

```
PCB Version : VER.A
```

```
BootROM Version : 510 ? 业务板Bootrom版本号
```

```
CPLD Version : 001
```

```
Software Version : S6503-3037 ? 主机软件版本号
```