

知 How does S9500 Check the Frame Type with Command?

刘志伟 2007-01-04 发表

You can use the hidden command `_display version` to view the frame type of the current device:

```
[S9500]_dis ver
```

```
H3C Comware Software
```

```
Comware Software, Version 3.10, Release 1277
```

```
Comware Platform Software Version COMWAREHZV300R001B08D025SP12
```

```
H3C S9505 Software Version V100R002B02D025SP11
```

```
H3C S9505 Product Version S9500-CMW310-R1277
```

```
Copyright(c) 2004-2006 Hangzhou H3C Tech. Co., Ltd. All rights reserved.
```

```
H3C S9505 uptime is 0 week, 0 day, 0 hour, 9 minutes
```

```
This device is H3C S9505E      ? Device mode
```

```
.....
```