

知 Why the Save Command Cannot Be Used to Save the Configuration File Before All LPUs Are Running Normally?

刘志伟 2007-01-04 发表

S9500 configuration is saved in the flash configuration file. When the board starts, it reads the configuration file and restore the default configuration of the board and save the running configuration. You can use the display saved-configuration to view the configuration in the configuration file and use the display current-configuration to view the configuration in the memory.

When all the boards are running normally, the configuration in the configuration file will be the same as that in the memory and you can use the save command to save the configuration in the memory to the configuration file.

Upon system start, if some LPUs are still not running normally, the configuration file is not completely restored to the memory. In that case, if you execute the save command, the incomplete configuration information in the memory will cover the configuration on file, resulting in loss of partial configuration information.