

孟维佳 2007-01-12 发表

On the upper right corner of the board panel is the silk screen for the board type, e.g. , "SRP1N4", "GP12B0", etc. Also, you can use the display device command to view t he board type, board status, board quantity, software version running on the board, e tc.