



## How to number ports of S9500

孟维佳 2007-01-12 发表

The port number of S9500 is numbered as "port type slot number/subslot number/port number", such as Ethernet 2/1/1 and Pos 2/1/1. When unmistakable, it can be abridged to Eth 2/1/1 or E 2/1/1, and the letters are case insensitive. The blank between port type and slot number can be omitted. Slots are numbered from 0 and the subslot and ports are numbered from 1.