



How to View ICMP Packets

刘志伟 2007-01-25 发表

Enable ICMP packet debugging in user view:

```
<S9500>terminal debugging
```

```
<S9500>terminal monitor
```

```
<S9500>debugging ip icmp
```