

MSR设备使用加密卡时如何调试IPSec数据包

Q: 使用加密卡时如何调试IPSec数据包?

A: 除了打开正常的IPSec调试开关, 还需要如下操作:

```
<msr>debugging encrypt-card ?
```

```
all    All encrypt-card debugging functions
```

```
error  Encrypt-card error debugging function
```

```
packet Encrypt-card packet debugging function
```

```
sa     Encrypt-card sa debugging function
```

```
<msr>debugging encrypt-card
```