

知 What Is the RS232/485 Interface of the MPU Used For at S9500?

孟维佳 2007-06-30 发表

RS232/485 interface is only used for managing the PoE power frame or extended power frame.