


The configuration of information center on H3C 5600 switch (no.3)

——log information has been sent to console

I Requirement for the diagram

1. Log information of the switch has been sent to console if the ponderance is higher than "informational". The modules that permit output are ARP and IP.

II Network topology.



III Steps of configuration

1. Start the information center

```
<H3C> system-view
```

```
[H3C] info-center enable
```

2. Shutdown the function that all modules send information to console

```
[H3C] undo info-center source default channel console
```

3. Configure the console's log sending. Only permit the log information that the ponderance is higher than "informational" has been sent to console. The modules that permit output are ARP and IP.

```
[H3C] info-center console channel console
```

```
[H3C] info-center source arp channel console log level informational debug state off trap state off
```

```
[H3C] info-center source ip channel console log level informational debug state off trap state off
```

4. Open the terminal display function

```
<H3C> terminal monitor
```

```
<H3C> terminal logging
```

IV Key notes in the configuration

None.