

Q: What to do if the enable password is lost on the mid-range router

A: Reboot the router and press **Ctrl+B** to enter the BootROM. Select **Clear application password** and reboot the router. After reboot, press **Enter** for several times to directly enter the privilege mode. Enter the config mode and run the **enable password** command. Then, change the enable password and save the configuration by writing in privilege mode.

The method of clearing password differs with the router version:

1. Version 97: Incapable of clearing password, upgrade to V2.0.

2. V2.0

1> Press **Shift+D** while power-on self-test to enter the download interface.

2> Type * after the password is displayed.

3> Type **Shift+3**, that is to enter #.

3. vrp1.0

1> Press **Ctrl+B** while power-on self-test to enter the download interface.

2> Press **Enter** by default after the password is displayed.

3> Type **Ctrl+P**.