

Mhy is a tilde displayed on the terminal after each command when the dum b terminal runs normally

冷志字 2007-09-27 发表

Q: Why is a tilde displayed on the terminal after each command when the dumb terminal runs normally?

A: The reason is that you use the one-to-one access mode but fail to perform the foll owing configuration on the terminal (that is, front-end processor): mode 1 #Set the access mode of dumb terminal to one-to-one (recommended) Add the command to the configuration file **ttyd.conf** of the front-end processor.